


Badelift bellavita

Kurzanleitung - Erstinstallation

1. Entnahme aus dem Karton und überprüfen des Arretierhebels







2. Rückenlehne abziehen



3. Sitzeinheit anheben




4. Durch den Transport kann sich der rote Arretierhebel aus den Aufnahmebohrungen lösen. Durch Drücken von oben kann er leicht wieder eingerastet werden. Bitte prüfen Sie den festen Sitz des Arretierhebels.

Einsetzen der Rückenlehne in die Sitzeinheit





1. Hinweis: Die Hubstange muss immer vollständig eingefahren sein.



2. **A**: Lagerbock – **B**: Rastnase Die Rastnasen der Rückenlehne jeweils in beide Lagerböcke der Sitzeinheit




3. Die eingesetzte Rückenlehne nach 4. Hinweis: hinten klappen bis sie am Anschlag der Bodenplatte aufliegt. Zum Entfernen ca. 45° nach vorn klappen und sitzt.

4. Hinweis.

Es ist unbedingt darauf zu achten, dass die Hubstange richtig in der Rampe sitzt.




. Aufladen des Akkus • Einstecken der Handbedienung • Pflege und Wartung



Nach Gebrauch Akku wieder laden. 1. Den Stecker 1) des Netzteils zuerst in die Buchse der Handbedienung 2) und den Netzstecker in eine Steckdose stecken. Beim Ladevorgang leuchtet die Kontrollleuchte rot. Ist der Akku geladen, leuchtet sie grün. Wenn der Akku vollständig aufgeladen ist, Handsteuerung vom Ladegerät trennen. Zuerst den Netzstecker ziehen.

Lagerung bei etwa 15-20 Grad Celsius empfehlenswert. Handsteuerung nicht auf den Heizkörper legen. Direkte Sonneneinstrahlung vermeiden.



- 2. Handbedienung Beschreibung:
- 1. Grün Einschalt-Taste
- 2. Rot: NOTAUS-Taste 3. Blau: Abwärts-Taste
- 4. Gelb: Aufwärts-Taste
- 5. Kontrolllampe



Klinkenstecker nicht mehr sichtbar ist.

3. Die Handbedienung am Rückenteil hinten einstecken. Hierzu die Buchse am Špiralkabel auf den Stecker schieben,

bis die Verriegelung spürbar einrastet und der rote Ring am

Falsch

4. Einsetzen und herausnehmen des Lifters in / aus der Badewanne



- Saugerlaschen der hinteren Sauger zeigen nach außen.
- Die Unterseite der Sauger müssen sauber und trocken sein, keine Rutschmatten und andere Gegenstände in die Badewanne einlegen.
- Einsetzen der Sitzeinheit in die leere Badewanne, so dass die hinteren Sauger am Anfang der Badewannenschräge aufliegen.



- Die Rückenlehne in die beiden Lagerböcke der Sitzeinheit einführen (siehe Punkt 2).
- Rückenlehne darf im abgesenkten Zustand nicht am Wannenrand aufliegen.

Rückenlehne nach hinten klappen.

Lifter zur Benutzung nach oben fahren.





- Rückenlehne entfernen (siehe Puntk 2).
- Haftsauger durch Ziehen an den Laschen belüften und das Untergestell am Tragegriff hochziehen und aus der Wanne nehmen.


Badelift bellavita

wir bewegen Ihr Leben

Quick User guide - First installation

1. Remove from the carton and check stop lever









4. Please ensure that the red seat unit locking mechanism is engaged by pushing down on the seat.

1. Raise the drive unit

2. Move the backrest forward


3. Raise the seat unit

. Attaching the backrest into the seat unit









2. A: Bearing block – B: Guide pin Slide the backrest into the hinge located it clicks into the latch. on the back of the seat unit.




3. Lift the backrest to an 45° Angle until 4. Important:



Please ensure that the actuator end is/ sits properly in the base plate's ramp.




3. Charging the battery • Attaching the hand control



Recharge the battery after application. 1. Place the plug 1) of the charger into the socket of the cable 2) attached to the hand control. During the charging process, the red light will be on. The light changes to green when the battery is fully charged. After fully charging the battery, please disconnect the charger from the hand control

Recommended value: Storage the hand control at room temperature. Don't place the hand control at a heater. Please avoid direct sunlight.



- 2. Hand control description:
- 1. Green: power On button
- 2. Red: emergency Stop
- 3. Blue: down button
- 4. Yellow: up button 5. Control light





3. Plug the hand control to the bathlift (at the back of the backrest). Make sure that the socket is properly seated on the jack and the red ring on the jack is now hidden.

wrong

4. Placing or removing the bathlift into/from the bathtub



- 1.
- Remove anti-slip mats or similar utilities.
- The tongues of the rear suction caps must be directed outwards.
- The suction cups at the bottom of the Bellavita must be clean and dry.
- Make sure that the rear suction cups are located close to the bevelled edge of the bath.



- Attention! It is very important that both quide pins are inserted into the bearing blocks! (see point 2).
- Pivot the attached backrest up until it reaches its final position.
- The backrest must not collide with the bathtub. In that case you have to reposition the bathlift.



3. Before usage, bring the lift into a position • wich allows seating comfortably.



- To remove, please turn 45° In advance and pull out. Remove backrest according point
- Remove the two rear suction cups by pulling the tongues. The seat unit can now be removed from the bathtub.

5. Side flap protectors (pair) - Installation and Usage (Accessories)



The bathlift side protectors should be used on baths fitted with grab handles or similar which protrude inside the bath.

To install the protectors, snap the hooked end over the grab handle and allow the long end to slide down the edge of the bath.

Once installed, the side flaps on the bathlift will slide against the protector rather than the edge of the bath. This removes the risk of the bathlift side flaps getting caught underneath the grab handles.

For longer bath handles, one or more protectors may be installed (as shown on picture).



